## brother

www.brother.eu

P-touch

P700 **User's Guide** English

Thank you for choosing the P-touch model P700. Your new P-touch uses P-touch Editor Lite software, which is already installed on your P-touch. There is no need to install any software or drivers onto your computer in order to make creative labels.

This manual includes important precautionary information and simple instructions for operating your new P-touch. Be sure to read the instructions before use and use the product in accordance with these instructions. Keep this manual handy for future reference. If new versions of the P700 software become available, this manual may not reflect the updated features. Therefore, you may find that the software and the contents in this guide are different.

D018G3001



## Safety Precautions

A WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.

#### Follow these guidelines to avoid the risk of fire, burns, injury, electric shocks, rupture, overheating, abnormal odours or smoke.

- Always use the specified voltage and the included AC adapter (AD-E001) for the P-touch to prevent any damage or failure.
- Do not touch the P-touch during a lightning storm.
- Do not use the P-touch/AC adapter in places of high humidity such as bathrooms. Do not overload the power cord.
- Do not place heavy objects on, or damage the P-touch, power cord or plug. Do not forcibly bend or pull the power cord. Always hold the AC adapter when disconnecting from the power socket.
- Make sure that the plug is fully inserted in the power socket. Do not use a socket that is loose.
- Do not allow the P-touch/AC adapter/power plug/batteries to get wet, for example, by handling them with wet hands or spilling beverages on to them.
- Do not disassemble or modify the P-touch/AC adapter/batteries.
- Do not allow a metal object to contact both the plus and minus ends of a battery. Do not use sharp objects, such as tweezers or a metallic pen, to change the batteries.
- Do not throw the batteries into fire or expose to heat.
- Disconnect the AC adapter, remove batteries immediately and stop using the P-touch if you notice abnormal odour, heat, discolouration, deformation or anything unusual while using or storing it.
- Do not use a damaged or leaking battery as the fluid may get on your hands. Do not use a deformed or leaking battery or one whose label is damaged. There is
- a possibility of damaging the P-touch. Since loss of eyesight may result when leaked fluid from batteries gets into your eyes, immediately rinse your eyes with a large amount of clean water, and then seek medical attention.

## A CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injuries.

#### Follow these guidelines to avoid personal injury, liquid leakage, burns or heat.

- When the P-touch is not being used, store it out of the reach of children. In addition, do not allow children to put any P-touch parts or labels in their mouths. If any object has been swallowed, seek medical attention.
- Do not touch metal parts around the print head immediately after printing.
- Do not touch the cutter blade. (See Parts Description.)
- If leaked fluid from batteries gets on your skin or clothes, immediately rinse them with clean water
- Remove the batteries and disconnect the AC adapter if you do not intend to use the P-touch.
- Do not use any batteries other than those specified. Do not use combinations of old and new batteries or combinations of different types, different charging levels, different manufacturers or different models. Do not insert a battery with its plus and minus ends reversed.
- Do not drop or hit the P-touch/AC adapter.
- Do not put your finger inside the P-touch when you close the cassette cover.
- Before using Ni-MH rechargeable batteries, carefully read the instructions for the batteries and battery charger, and be sure to use them correctly.
- When using Ni-MH rechargeable batteries, charge the batteries with a specialized battery charger before using the batteries.

## **General Precautions**

- Depending on the location, material, and environmental conditions, the label may unpeel or become irremovable, the colour of the label may change or be transferred to other objects. Before applying the label, check the environmental conditions and the material
- Do not use the P-touch in any way or for any purpose not described in this guide. Doing so may result in accidents or damage to the P-touch. Use Brother TZe tapes with the P-touch.
- Only use a soft, dry cloth to clean the P-touch; never use alcohol or other organic solvents.
- Use a soft wipe to clean the print head; never touch the print head with your fingers. Do not put any foreign objects into the tape exit slot or AC adapter connector or battery compartment, etc.
- Do not place the P-touch/batteries/AC adapter in direct sunlight or rain, near heaters or other hot appliances, in any location exposed to extremely high or low temperatures (e.g., on the dashboard or in the back of your car) or high humidity,
- or in dusty locations. Do not try to print if the cassette is empty; it will damage the print head. Do not pull the tape while printing or feeding; it will damage the tape and the P-touch. Any data stored in memory will be lost due to failure or repair of the P-touch, or if the batteries expire.
- The P-touch is not equipped with a charging feature for rechargeable batteries. The length of the printed label may differ from the displayed label length on the computer.
- A protective clear plastic sticker is placed over the top panel during manufacturing and shipping. This sticker should be removed prior to use.
- When printing multiple copies of a label or using the numbering function printing, the P-touch will not detect the end of the tape cassette and will continue operating.
- When using Heat Shrink Tube, the printing area will be smaller than when using normal tape
- Do not scratch or subject the CD-ROM to high or low temperatures
- Do not put heavy objects on the CD-ROM or apply force to the CD-ROM. The software contained on the CD-ROM is meant for use with this P-touch only.

See the Licence on the CD-ROM for details	. This software may be installed on
multiple computers for use in an office, etc.	-

### Declaration of Conformity (Europe/Turkey only)

We. Brother Industries, Ltd. 15-1, Naeshiro-cho, Mizuho-ku, Nagoya 467-8561 Japan

#### Information for compliance with Commission Regulation 801/2013

Power consumption\* 2.0 W

\* All network ports activated and connected

Responsible Farty.	Brother International Corporation 200 Crossing Boulevard P.O. Box 6911 Bridgewater, NJ 08807-0911 USA TEL: (908) 704-1700
declares that the pro Product Name: Model Number:	ducts Brother P-touch Electronic Labeling System PT-P700
(1) this device may no interference received This equipment has to device, pursuant to F reasonable protection equipment generates	including interference, and (2) this device must accept ar , including interference that may cause undesired operation. Deen tested and found to comply with the limits for a Class B digit Part 15 of the FCC Rules. These limits are designed to provide n against harmful interference in a residential installation. This
<ul> <li>and used in accorda communications. Ho particular installation television reception, user is encouraged t measures:</li> <li>Reorient or relocal</li> <li>Increase the sepai</li> <li>Connect the equip receiver is connec</li> <li>Consult the dealer</li> </ul>	s, uses, and can radiate radio frequency energy and, if not install nce with the instructions, may cause harmful interference to radio wever, there is no guarantee that interference will not occur in a . If this equipment does cause harmful interference to radio or which can be determined by turning the equipment off and on, t o try to correct the interference by one or more of the following te the receiving antenna. ration between the equipment and receiver. ment into an outlet on a circuit different from that to which the ted. or an experienced radio/TV technician for help.



## **Unpacking the P700**

Check that the package contains the following before using the P-touch. If any item is missing or damaged, contact your Brother reseller.

- P700
- AC adapter (AD-E001) · User's Guide
- CD-ROM
  - **Parts Description**





USB cable

Starter tape cassette

- Top panel Editor Lite lamp 2 3 4 5 Editor Lite button
- Tape exit slot
- Feed & Cut button
- Status lamp
- 6 7 8 Power button
- Battery cover



#### 11 Cassette cover 12 Release lever 13 Print head 14 15 Tape cutter Cutter blade

Setting the Tape Cassette

1. Place the P-touch so that the cassette cover is facing upwards, then open the cassette cover.

## **A** CAUTION

Do not put your finger inside the tape exit slot. You could be injured by the cutter blade.

Insert a tape cassette and close the cassette cover. Restore the P-touch to an upright position. 2.





# Connecting the Power Supply

#### Using the AC adapter

When using the included AC adapter (AD-E001), insert the plug on the adapter cord into the AC adapter connector of the P-touch. Insert the plug into the nearest standard electrical socket.



## Using the batteries

When using the P-touch with batteries, open the battery cover on the bottom of the P-touch, insert six "AA" alkaline batteries (LR6) or Ni-MH rechargeable batteries (HR6), making sure that their poles point in the correct directions, and then close the battery cover. Always replace all six batteries at the same time using new batteries or fully charged rechargeable batteries.



## Creating a Label using P-touch Editor Lite

1. Turn on the P-touch, then press and hold down the Editor Lite button until the green Editor Lite lamp liahts up.



2. Connect the USB cable to the computer.

#### NOTE

If you are connecting the P-touch via a USB hub, it may not be detected correctly.



3. After the USB cable is connected, a dialog box appears on the computer display. (The following screens may differ depending on the operating system on your computer.)

#### For Windows Vista<sup>®</sup>

Click [P-touch Editor Lite]

P	- • ×
P-TOUCH (G:)	
E Mango do Mio for software	and genesi
P-touch Editor Lite	
L in the set	
International Advancement	alfana .

#### For Windows<sup>®</sup> 7

Click [Open folder to view files], and then double-click [PTLITE10].

- • ×	1	<b>~</b>		1.10		
P-TOUCH (E:)		Q	PT-P700 (E:) •	• 49	88	• 11 (
and agrices (and black is say fire) and having galax is Carter/Freed		r it faurita ■ Desting it Desting it Desting it fauritation it fauritation	Start Here Mac.app ₿ PTLITE10.EXE	Data modified 318/2013 Add Pere 3127/2012 Bull Pere	Tapa File folder Application	344

#### For Windows<sup>®</sup> 8

On the [Start] screen, click [PT-P700], [Open folder to view files], and then double-click [PTLITE10]

19   🕞 🖪 =	Break Tools	PT-P700 (	E:)	-	×
Per Part Da	en View Manage				~ Ø
⊕ ∋ - ↑ 🖗 ו	▶ PT-P700 (E:) ►		~ ¢	Search PT #782 (5.)	Q
12 Facester	Theres	Date modified	Tape	Time	
During During	〕】 Start Here Mac.app ❷ PTLITE10	3/16/2012 3-40 PM 3/27/2012 6-17 PM	File folder Application	744.00	

#### For Mac OS X v10.6.8 - v10.8.x

Double-click [PT-P700] on the desktop and the [P-touch Editor Lite] application icon.



#### NOTE

- If you do not see the dialog box, it may be hidden behind an open software program window. Minimize all windows to show the dialog box. (For Windows  $^{\textcircled{B}}$ )
- (For Windows<sup>®</sup>) It will take longer than usual to start P-touch Editor Lite when connecting the P-touch to your computer for the first time. If the software does not start automatically when you connect the P-touch, you may launch it from [**My Computer**]. Start P-touch Editor Lite by double-clicking [**PTLITE10.EXE**]. (For Windows Vista<sup>®</sup>) When connecting the device for the first time, perform the scan and then select the [**Always do this for software and games**] check box on the dialog box displayed when the scan finishes. P-touch Editor Lite will start automatically the next time you connect the P-touch.

P-touch Editor Lite starts. For details on using P-touch Editor Lite, see the Software User's Guide included on the CD-ROM (for Windows<sup>®</sup>) or download the Software User's Guide by visiting the Brother support website at <u>support.brother.com</u> (for Macintosh). Macintosh users can access this URL directly by clicking the support is found in CD-ROM. 4.

(For Windows <sup>®</sup> )	(For Macintosh)

#### IMPORTANT

Do not turn off the power or disconnect the P-touch while using P-touch Editor Lite



## How to Disconnect the P-touch

#### For Windows<sup>®</sup>

- 1. Exit P-touch Editor Lite by clicking on the 🔀 in the top right corner of the window if using P-touch Editor Lite
- 2. To disconnect the P-touch, click the icon in the computer's task bar (w, , , , or ).
- 3. Click [Safely remove USB Mass Storage Device].
- 4. When the message indicating that the device can be safely removed is displayed, turn off the P-touch and disconnect the USB cable.

#### For Macintosh

- Exit P-touch Editor Lite by clicking on the red button in the top left corner of the window, if using the P-touch Editor Lite. 1.
- Select [PT-P700] on the desktop, and then perform one of the following:
  Select [Eject] from the Context menu.
  Drag and drop it in the Trash. 2
- When a message indicating that the device can be safely removed is displayed, turn off the P-touch and disconnect the USB cable. 3.



If you want to use a more advanced application, you are able to install P-touch Editor 5.1 for Windows<sup>®</sup> and P-touch Editor 5.0 for Macintosh. This software will give you greater label making functionality. For details on using P-touch Editor, see the Software User's Guide included on the CD-ROM (for Windows<sup>®</sup>) or download the Software User's Guide by visiting the Brother support website at <u>support.brother.com</u> (for Macintosh).

#### IMPORTANT

Before connecting the USB cable to the computer, check the Editor Lite lamp is not lit. If the Editor Lite lamp is lit, press and hold down the Editor Lite button until the lamp goes off.

#### Installing the Printer Driver and Software

For Windows<sup>®</sup>

- 1. Start the computer and put the CD-ROM into the CD-ROM drive.
- 2. Follow the on-screen instructions to complete setup



#### NOTE

(For Windows<sup>®</sup> 8 only) Use Adobe<sup>®</sup> Reader<sup>®</sup> to open the PDF manuals on the CD-ROM. If Adobe<sup>®</sup> Reader<sup>®</sup> is installed but cannot open the files, change the ".pdf" file association to "Adobe<sup>®</sup> Reader<sup>®</sup>" from the control panel.

#### For Macintosh

You can download the driver, software and manuals by visiting the Brother support website at support brother.com Macintosh users can access this URL directly by clicking the 💱 icon found in CD-ROM.

#### Starting P-touch Editor

#### For Windows Vista<sup>®</sup> / Windows<sup>®</sup> 7

From the Start menu, click [All Programs] - [Brother P-touch] - [P-touch Editor 5.1]. P-touch Editor 5.1 starts.

#### For Windows<sup>®</sup> 8

Click [P-touch Editor 5.1] on the [Start]/[Apps] screen or double-click [P-touch Editor 5.1] on the desktop. P-touch Editor 5.1 starts

#### For Mac OS X v10.6.8 - v10.8.x

Double-click [Macintosh HD] - [Applications] - [P-touch Editor 5.0] and then [P-touch Editor] application icon.



Using the Device Settings

With [Device settings] in the [Printer Setting Tool], default printer settings can be changed.

#### IMPORTANT

- Before connecting the USB cable to the computer, check the Editor Lite lamp is not lit. If the Editor Lite lamp is lit, press and hold down the Editor Lite button until the lamp goes off.
- Make sure that the AC adapter is connected to an AC power socket.
- Make sure that the printer driver has been installed and is functional.
- Connect this printer to a computer with a USB cable

2. For Windows Vista<sup>®</sup>/Windows<sup>®</sup> 7: From the Start menu, click [All Programs] - [Brother] - [Label & Mobile Printer] - [Printer Setting Tool]. For Windows<sup>®</sup> 8: On the [Start] or [Apps] screen, click [Printer Setting Tool]. For Mac OS X v10.6.8 - v10.8.x: Click [Macintosh HD] - [Applications] - [Brother] - [P-touch Utilities] - [Brother P-touch Utility.app]. The main window appears.

- Select the P-touch to be configured from the [**Printer**] drop-down list and then click [**Device settings**]. The [**Device settings**] window appears. 3.
- 4. Specify or change the settings. (The screen below is from Windows<sup>®</sup>.)

l	
1— 2—	The large and the large at the
3—	Tota Manada Awat
4— 5—	

#### 1 Power On when Plugged in

Select whether or not the printer turns on automatically when the AC power cord is plugged into an AC power socket.

- Available settings: [Enable], [Disable] 2 Auto power off when AC adapter is connected
- Specify the amount of time that passes before the printer turns off automatically. Available settings: [None], 10/20/30/40/50 minutes, 1/2/4/8/12 hours
- Contents

Specifies the printer information that will be printed. Available settings: [AII], [Usage Log], [Printer Settings]

4 Length adjustment

Adjusts the length of the printed label to correspond to the length of the label displayed on the computer

- Available settings: -3 to +3% (1% increments) Print test
- 5 Prints a test label to check the results of the length adjustment.
- Menu Bar 6
  - [File] [Apply Settings to the Printer]
    - Applies the settings to the printer. Performs the same operation as when the [Apply] button is clicked.
    - [File] [Import]
    - Imports the exported file and applies the settings to this tool. • [File] - [Export]
    - Saves the current settings in a file
    - [Tools] [Print Information Report]
    - Prints the printer information
    - [Tools] [Reset to Factory Defaults]
    - Returns all printer settings to their factory defaults.
    - [Tools] [Option Settings]
    - If the [Do not display an error message if the current settings cannot be retrieved at startup] check box is selected, a message will not be displayed next time
- 7 **Current Settings**
- Click this button to retrieve the settings from the currently connected printer and display them in the dialog box.
- 5. After changing the settings, click [Apply] - [Exit], and then click [Exit] in the main window to finish specifying settings

## Uninstalling the Printer Driver and the Software

#### Uninstalling the printer driver

Perform this procedure only if printing from the P700 is no longer necessary or when re-installing the P700 printer driver

#### For Windows Vista<sup>®</sup>

- **1.** Turn off the P-touch.
- 2. From the Start menu, click [Control Panel] [Hardware and Sound] [Printers].
- 3. Select [Brother PT-P700] and click [Delete this printer], or right-click the icon and click [Delete].
- 4. Right-click the [Printers] window, and then click [Run as administrator] - [Server Properties...]. If the authorisation confirmation window appears, click [Continue]. If the [User Account Control] window appears, type in the password, and then click [OK]. The [Print Server Properties] window appears.
- 5. Click the [Drivers] tab, select [Brother PT-P700], and then click [Remove...].
- Select [Remove driver and driver package], and then click [OK].
- 7. Close the [Print Server Properties] window. The printer driver has been uninstalled.

1. Connect the P-touch to be configured to the computer.

#### For Windows<sup>®</sup> 7

- 1. Turn off the P-touch
- 2. From the Start menu, click [Devices and Printers].
- Select [Brother PT-P700] and click [Remove device], or right-click the icon and click [Remove device]. If a User Account Control message appears, type in the password, and then click [Yes].
- 4. Select [Fax] or [Microsoft XPS Document Writer] in the [Devices and Printers] window, and then click [Print server properties], which appeared on the menu bar.
- Click the [Drivers] tab, and then click [Change Driver Settings]. If a User Account Control message appears, type in the password, and then click [Yes]. Select [Brother PT-P700], and then click [Remove...].
- **6.** Select [**Remove driver and driver package**], and then click [**OK**]. Follow the on-screen instructions.
- 7. Close the [Print Server Properties] window. The printer driver has been uninstalled.

#### For Windows<sup>®</sup> 8

- **1.** Turn off the P-touch.
- 2. Click [Control Panel] on the [Apps] screen [Hardware and Sound] [Devices and Printers].
- Select [Brother PT-P700] and click [Remove device], or right-click the icon and click [Remove device].
   If a User Account Control message appears, type in the password, and then click [Yes].
- 4. Select [Fax] or [Microsoft XPS Document Writer] in the [Devices and Printers] window, and then click [Print server properties], which appeared in the menu bar.
- **5.** Click the [**Drivers**] tab, and then click [**Change Driver Settings**]. If a User Account Control message appears, type in the password, and then click [**Yes**]. Select [**Brother PT-P700**], and then click [**Remove...**].
- 6. Select [Remove driver and driver package], and then click [OK]. Follow the on-screen instructions.
- 7. Close the [Print Server Properties] window. The printer driver has been uninstalled.

#### For Mac OS X v10.6.8 - v10.8.x

- **1**. Turn off the P-touch.
- 2. Click [Apple menu] [System Preferences], and click [Print & Fax] (OS X v10.6.8) / [Print & Scan] (OS X v10.7.x/v10.8.x).
- 3. Choose [Brother PT-P700], and click [-].
- **4.** Close the [**Print & Fax**] (OS X v10.6.8) / [**Print & Scan**] (OS X v10.7.x/v10.8.x) window. The printer driver has been uninstalled.

### Uninstalling the software

Perform this procedure only if the software is no longer necessary or when re-installing the software. To uninstall the software, follow the usual steps for your operating system.

# **10** Definition of the Status Lamp

The Status lamp on the P-touch indicates the current operating condition.

Lamp	Condition
Not lit	Power is OFF.
Green lamp is lit	Power is ON.
Green lamp is flashing	Receiving data from the computer. Transferring data.
Orange lamp is lit	The cassette cover is open. Close the cassette cover correctly. Starting the reset procedure, or the Feed & Cut button was pressed during the reset procedure. For details on resetting the P-touch, see Troubleshooting.
Orange lamp is flashing	Cooling (Wait for the temperature to cool down) Reset in progress. For details on resetting the P-touch, see Troubleshooting.
Red lamp is lit	The P-touch is booting.
Red lamp is flashing	Indicates one of the following errors. Red lamp flashes in 0.9 second intervals: • No tape cassette • Incorrect tape cassette installed • Incompatible tape cassette installed • The cassette cover was opened during printing • Transmission error • Overheating error • Cutter error Red lamp flashes in 0.3 second intervals: • System error



Problem	Solution
After exiting P-touch Editor Lite, how do I restart the program while the P-touch is still on?	<ul> <li>There are three ways to restart. Perform any of the following.</li> <li>Turn off the P-touch and then turn it back on.</li> <li>Disconnect and then reconnect the USB cable while the P-touch is on.</li> <li>(For Windows<sup>®</sup>) Launch P-touch Editor Lite from [My Computer].</li> </ul>
I cannot turn the P-touch on.	Check to see that the batteries are installed correctly, or that the included power adapter is securely connected.
I cannot exit P-touch Editor Lite.	Check to see if an error message is displayed, and try to resolve it. Please note that the software cannot be exited while labels are being printed.
A blank horizontal line appears through the printed label.	Streaks or poor quality characters on printed labels generally indicate that the print head is dirty. Clean the print head using a cotton swab or optional print head cleaning cassette (TZe-CL4). * Do not touch the print head directly with your bare hands.
The label is difficult to cut.	Clean the cutter blade using a cotton swab moistened with alcohol. * Do not touch the cutter blade directly with your bare hands.
When the label is printed out, there is too much margin (space) on both sides of the text.	When margins are set to [Large], labels print with approx. 25 mm margins on each side of the printed text. Reduce this margin by changing the setting to [Small]. On P-touch Editor Lite, right-click the mouse and select [Margins] from the displayed menu. Change the setting to [Small].
The P-touch does not print, or the printed characters are not formed properly.	<ul> <li>Check that the tape cassette has been inserted correctly.</li> <li>If the tape cassette is empty, replace it.</li> <li>Check the cassette cover is properly closed.</li> </ul>
The power turns off when you try to print.	<ul> <li>The batteries may be weak. Replace them.</li> <li>Check that the batteries are correctly inserted.</li> <li>An incorrect adaptor is being used; the recommended adapter is the AD-E001.</li> </ul>
The tape does not feed properly, or the tape gets stuck inside the P-touch.	<ul> <li>Check that the end of the tape feeds under the tape guides.</li> <li>The Feed &amp; Cut button was used while printing. Do not touch the Feed &amp; Cut button during printing.</li> </ul>
I want to reset the P-touch.	With the P-touch off, press and hold the Feed & Cut button while holding down the Power button. When the Editor Lite lamp starts flashing and the Status lamp lights orange, press the Feed & Cut button six times while continuing to hold down the Power button. The P-touch will be reset to the factory settings.

# 2 Specifications

Product Specifications	
Dimensions (W $\times$ D $\times$ H)	Approximately 78 mm (W) × 152 mm (D) × 143 mm (H)
Weight	Approximately 710 g (without batteries and tape cassette)
Power supply	AC adapter (AD-E001) Six "AA" alkaline batteries (LR6) <sup>*1</sup> Six "AA" Ni-MH rechargeable batteries (HR6) <sup>*1, *2</sup>

<sup>\*1</sup> Not included.

<sup>\*2</sup> Visit us at <u>support.brother.com</u> for the latest information about the recommended batteries.

Accessories	
Tape cassette	Brother TZe tape (width) 3.5 mm, 6 mm, 9 mm, 12 mm, 18 mm, 24 mm
AC Adapter	AD-E001

System Requirements	Windows <sup>®</sup>	Macintosh
Operating System	Windows Vista <sup>®</sup> / Windows <sup>®</sup> 7/Windows <sup>®</sup> 8	Mac OS X v10.6.8 OS X v10.7.x, 10.8.x
Hard-Disk Free Space	70 MB or more	500 MB or more
Memory	Windows Vista <sup>®</sup> : 512 MB or more Windows <sup>®</sup> 7/Windows <sup>®</sup> 8: 1 GB (32-bit) or 2 GB (64-bit) or more	Mac OS X v10.6.8: 1GB or more OS X v10.7.x, 10.8.x: 2GB or more
Display	SVGA/High Colour or more	More than 256 colours

Please see the Brother support website (support.brother.com) for the latest compatible OS.